

DR'G. No. MA328


WIRING DIAGRAM FOR

LUCAS "MAGDYNO" OR SEPARATE DYNAMO LIGHTING EQUIPMENT

AS FITTED TO MOTOR-CYCLES

SPECIFICATION

"MAGDYNO" TYPE MS.
OR SEPARATE DYNAMO
HEADLAMP TYPE
DU142D OR DU42D



INSTRUCTIONS ON HEADLAMPS

TYPES DU42D AND DU142D.
The lamp front and reflector can be withdrawn for bulb replacement when the fixing clip is pressed back. When re-fitting, locate top of rim first. To remove bulb holder, press back the two securing springs. With some lamps the main bulb can be focussed by removing the lamp front and reflector and slackening the clamping screw which secures bulb holder. Move the bulb and holder until the best results are obtained and finally tighten the clamping screw.