

Equipment Specification

A.J.S. 250 c.c. o.h.v. '14 Sapphire', '14S Sapphire Sports and '14CS Scorpion' 1959-62 350 c.c. o.h.v. '8 Senator' 1960-62

Unit	Year	Part No.	Model
Battery	1959-62	—	†PUZ7E-11
"	1959-61	*70146B (70142)	HF1849
"	1962	70163A	8H

A.J.S. 350 c.c. o.h.v. '16MS' 1958 and '16 Sceptre' and '16S Sceptre Sports' 1959-62

Unit	Year	Part No.	Model
Alternator	1958-62	423506	RM15
Rotor	1958-62	47122A	RM15
Stator	1958-62	36084F	CZU27
Ammeter (part of headlamp)	1958-59	—	PUZ7E-11
Battery	1960-61	—	MLZ9E
"	1962	—	PUZ7E-11
Cable harness	1958-59	865225	—
"	1960-62	54944148	—
"	1962	54949913	—
Coil, ignition	1958-62	45077B/E	MA6
Contact breaker	1958-61	47578D/H	CA1A
"	1962	47595A	CA1A
Generator	1958-62	20038	E3N
Horn	1958-61	*70137A (70048)	HF1441
"	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958-59	58135A	MCH57
ditto	1960-62	58409A	MCH61
ditto	1962	58702A	MCH61
Export, vertical dip	1958-59	58136A	MCH57
Export Europe (not France)	1958-59	58137A	MCH57
ditto	1960-62	58514A	MCH61
ditto	1962	58832A	MCH61
Export France	1958-59	58138A	MCH57EF
"	1960-62	58515A	MCH61EF
"	1962	58833A	MCH61EF
Stop tail and number plate and reflex	1958-62	53432B	564
Rectifier	1958-59	*47111A (47132)	FSW1501A
"	1959-62	47132A/B	FSX1849
Switches			
Ignition (part of headlamp)	1960-62	54033027	63SA
ditto	1962	34287A	88SA
Knob	1960-62	54332498	—
Lighting (part of headlamp)	1960-62	54033109	63SA
ditto	1962	34289A	88SA
Knob	1962	54330934	—
Lighting and ignition (part of headlamp)	1958-59	31443E	PRS8
Knob	1958-59	318346	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

A.J.S. 350 c.c. o.h.v. '16MC', '16C', '16CS' and '16C Experts' (Competition Models) 1958-62

Unit	Year	Part No.	Model
Ammeter (part of headlamp)	1958-62	36084F	CZU27
Battery	1958-62	—	PUZ7E-11
Cable harness	1958	838671	—
"	1959-61	54941907	—
"	1962	54949915	—
Control box	1958	37144A	MCR2
"	1958	37144B	MCR2
"	1959-60	37232H	RB108
"	1960-62	37232J/K	RB108
Generator	1958-62	20038B	E3N
Horn	1958-61	*069446 (54068034)	HF1234
"	1962	70163A	8H
Horn push	1958-61	76204A	4A
Horn push and dip switch	1962	31563D	25SA

continued

The Lucas Equipment shown in the following specifications is that fitted to the machines originally. It will be noted that certain items are starred. These are no longer obtainable, and the part number shown beneath in brackets must be quoted when ordering.

Spare parts for all the units shown in these specifications are tabulated in various sections of this catalogue.

A.J.S. 350 c.c. o.h.v. '16MC', '16C', '16CS' and '16C Experts' (Competition Models) 1958-62 —continued

Unit	Year	Part No.	Model
LAMPS			
Head			
Home and Export	1958	*50791D (51625)	MU42
"	1959-62	58224D	SSU700P
Stop tail and number plate	1958	53432B	564
ditto (U.S.A. only)	1958	53429A	529
ditto	1959-62	53429A/B	529
Magneto	1958-62	*42347D (42371)	NC1
"	1962	*42347E (42371)	NC1
" (U.S.A. only)	1958-62	42371A	NC1
Reflex reflector	1960-62	57116A	RER25
Switches			
Dipper	1958-61	31482A	9
Lighting (part of headlamp)	1958	31340A	U39
"	1959-62	*31754A/B (31763)	41SA
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

A.J.S. 500 c.c. o.h.v. '18' and '18S Statesman' 1958-62

Unit	Year	Part No.	Model
Alternator	1958-62	423506	RM15
Rotor	1958-62	47122A	RM15
Stator	1958-62	36084F	CZU27
Ammeter (part of headlamp)	1958-59	—	PUZ7E-11
Battery	1960-61	—	MLZ9E
"	1962	—	PUZ7E-11
Cable harness	1958-59	865225	—
"	1960-62	54944148	—
"	1962	54949913	—
Coil, ignition	1958-62	45077B/E	MA6
Contact breaker	1958-62	47579D/H	CA1A
Horn	1958-61	*70137A (70048)	HF1441
"	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958-59	58135A	MCH57
ditto	1960-62	58409A	MCH61
ditto	1962	58702A	MCH61
Export, vertical dip	1958-59	58136A	MCH57
Export Europe (not France)	1958-59	58137A	MCH57
ditto	1960-62	58514A	MCH61
ditto	1962	58832A	MCH61
Export France	1958-59	58138A	MCH57EF
"	1960-62	58515A	MCH61EF
"	1962	58833A	MCH61EF
Stop tail and number plate and reflex	1958-62	53432B	564
Rectifier	1958-59	*47111A (47132)	FSW1501A
"	1959-62	47132A/B	FSX1849
Switches			
Ignition (part of headlamp)	1960-62	54033027	63SA
ditto	1962	34287A	88SA
Knob	1960-62	54332498	—
Lighting (part of headlamp)	1960-62	54033109	63SA
ditto	1962	34289A	88SA
Knob	1962	54330934	—
Lighting and ignition (part of headlamp)	1958-59	31443E	PRS8
Knob	1958-59	318346	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

A.J.S. 500 c.c. o.h.v. '18CS', '18CT' and '18CS Southerner' (Competition Models) 1958-62

Unit	Year	Part No.	Model
Alternator	1960-62	423506	RM15
Rotor	1960-61	47122A	RM15
Stator	1962	47154A	RM15
Ammeter (part of headlamp)	1958-62	36084F	CZU27

continued

* When ordering, quote part number shown in brackets

† Suitable Lucas replacement



Equipment Specification

JAMES—MATCHLESS

JAMES 147 c.c. t.s. 'Cadet L15' 1958-59 and
149 c.c. 'Flying Cadet L15A' 1960-62

—continued

Unit	Year	Part No.	Model
Battery	1960-61	—	PUZ5E-11
	1962	—	PUZ5E-10
Cable harness (direct lighting)	1958-59	838981	—
	1958-59	838971	—
Horn	1958-59	*†70146A/B (70142)	HF1849
Horn push and dip switch	1958-59	31563D	25SA
LAMPS			
Head			
Home and Export, dip left (grey, direct)	1958-59	58111A	MCH56
Home and Export, dip left (maroon, direct)	1958-59	58149A	MCH56
Home and Export, dip left (grey, rectified)	1958-59	58112A	MCH56
Home and Export, dip left (maroon, rectified)	1958-59	58150A	MCH56
Switches			
Lighting (rectified) .. .	1958-59	31718A	41SA
(direct) .. .	1958-59	31721B	41SA

JAMES 149 c.c. t.s. Scooter 'SC1' 1962

Battery	1962	—	MLZ9E
Horn	1962	70163A	8H

JAMES 175 c.c. t.s. 'Cavalier L17' 1958-59

Alternator			
Rotor	1958-59	54210413	RM13
Stator	1958-59	468678	RM13
Ammeter	1958-59	36084F	CZU27
Battery	1958-59	—	PUZ5E-10
Cable harness	1958-59	54940078	—
Coil, ignition	1958-59	45077B/E	MA6
Contact breaker	1958-59	47573D	IMP52
Horn	1958-59	*†70146B (70142)	HF1849
LAMPS			
Head			
Home and Export, dip left (grey)	1958-59	51997B	MCH56
Home and Export, dip left (maroon)	1958-59	58259A	MCH56
Switches			
Lighting	1958-59	31443E	PRS8
Knob	—	318346	—

JAMES 197 c.c. 'Captain K7' 1958-59
199 c.c. t.s. 'Captain L20' 1960-62 and
'Sports Captain L20S' 1962

Alternator			
Rotor	1960-61	466125	RM13
Stator	1960-61	468678	RM13
Ammeter (in headlamp) .. .	1958-61	36084F	CZU27
Battery	1958-59	—	PUZ7E-10
	1960-62	—	PUZ7E-11
Cable harness	1958-59	54940310	—
Coil, ignition	1960-61	45077A/E	MA6
Contact breaker	1960-61	47574F	3CA
Horn	1958-62	*70146A/B (70142)	HF1849
Horn push and dip switch	1958-59	31563D	25SA
LAMPS			
Head			
Home and Export, vertical dip (grey)	1958-59	58216A	MCH56
Home and Export, vertical dip (maroon)	1958-59	58215A	MCH56
Home and Export, vertical dip (grey)	1960-61	58348A	MCH56
Home and Export, vertical dip (maroon)	1960-61	58349A	MCH56
Rectifier	1960-61	47132B	FSX1849
Switches			
Lighting (in headlamp) .. .	1958-59	31758A	41SA
" " " "	1960-61	31443A/E	PRS8

JAMES 249 c.c. t.s. 'Commodore L25' 1958-62 and
'Super Swift M25' 1962

Battery	1958-62	—	PUZ7E-11
Horn	1958-62	*70146A/B (70142)	HF1849
Horn push and dip switch	1958-59	31563D	25SA

MATCHLESS 250 c.c. o.h.v. 'G2', 'G2CS' and
'Clubman' 1959-62
'G2 Monitor' and 'G2S Monitor
Sports' 1962 and
350 c.c. o.h.v. 'G5 Matador' 1960-62

Unit	Year	Part No.	Model
Battery	1959	—	†PUZGE-11
	1960-62	—	†PUZ7E-11
Horn	1959-61	*70146B (70142)	HF1859
" " " "	1962	70163A	8H

MATCHLESS 350 c.c. o.h.v. 'G3LS' 1958 and
'G3 Mercury' and 'G3S Mercury
Sports' 1959-62

Alternator			
Rotor	1958-62	423506	RM15
Stator	1958-62	47122A	RM15
Ammeter (part of headlamp) .. .	1958-62	36084F	CZU27
Battery	1958-59	—	PUZ7E-11
	1960-61	—	MLZ9E
	1962	—	PUZ7E-11
Cable harness	1958-59	865225	—
	1960-62	54944148	—
" " " "	1962	54949913	—
Coil, ignition	1958-62	45077B/E	MA6
Contact breaker	1958-61	47578D/H	CA1A
	1962	47595A	CA1A
Horn	1958-61	*70137 (70048)	HF1441
	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958-59	58135A	MCH57
" " " "	1960-62	58409A	MCH61
" " " "	1962	58702A	MCH61
Export, vertical dip	1958-59	58136A	MCH57
Export Europe (not France)	1958-59	58137A	MCH57
" " " "	1960-62	58514A	MCH61
" " " "	1962	58832A	MCH61
Export France	1958-59	58138A	MCH57EF
" " " "	1960-62	58515A	MCH61EF
" " " "	1962	58833A	MCH61EF
Stop tail, number plate and reflex	1958-62	53432B	564
Rectifier	1958-59	*47111A (47132)	FSW1501A
" " " "	1959-62	47132A/B	FSX1849
Switches			
Ignition (part of headlamp)	1960-62	54033027	63SA
ditto	1962	34287A	88SA
Knob	—	54332498	—
Lighting (part of headlamp)	1960-62	54033109	63SA
ditto	1962	34289A	88SA
Knob	—	54330934	—
Lighting and ignition (part of headlamp) .. .	1958-59	31443E	PRS8
Knob	—	318346	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

MATCHLESS 350 c.c. o.h.v. 'G3LCS', 'G3C',
'G3CS' and 'G3C Maestro' (Competition Models) 1958-62

Ammeter (part of headlamp) .. .	1958-62	36084F	CZU27
Battery	1958-62	—	PUZ7E-11
Cable harness	1958	838671	—
	1959-61	54941907	—
	1962	54949915	—
Control box	1958	37144A	MCR2
" " " "	1958	37144B	MCR2
" " " "	1959-60	37232H	RB108
" " " "	1960-62	37232J/K	RB108
Generator	1958-62	20038B	E3N
Horn	1958-61	*069446 (54068034)	HF1234
" " " "	1962	70163A	8H
Horn push	1958-61	76204A	4A
Horn push and dip switch	1962	31563D	25SA
LAMPS			
Head			
Home and Export	1958	*50791D (51625)	MU42
" " " "	1959-62	53224D	SSU700P
Stop tail and number plate .. .	1958	53432B	564
ditto (U.S.A. only)	1958	53429A	529
ditto	1959-62	53429A/B	529
Magneto	1958-62	*42347D (42371)	NC1
" " " "	1962	*42347E (42371)	NC1

continued

* When ordering, quote part number shown in brackets

† Suitable Lucas replacement



Equipment Specification

MATCHLESS

MATCHLESS 350 c.c. o.h.v. 'G3LCS', 'G3C', 'G3CS' and 'G3C Maestro' (Competition Models) 1958-62—contd.

Unit	Year	Part No.	Model
Magneto (U.S.A. only)	1958-62	42371A	NC1
Reflex reflector	1960-62	57116A	RER25
Switches			
Dipper	1958-61	31482A	9
Lighting (part of headlamp)	1958	31340A	U39
ditto	1959-62	*31754A/B (31763)	41SA
Stop lamp	1958-62	31384B	22B
Spring, stop lamp		315543	—

MATCHLESS 500 c.c. o.h.v. 'G50CSR' (Export U.S.A. only) 1962

Ammeter (part of headlamp)	1962	36296A	2AR
Battery	1962	—	MLZ9E
Cable harness	1962	54931326	—
Control box	1962	37232K	RB108
Generator	1962	20038B	E3N
Horn	1962	70163A	8H
Horn push and dip switch	1962	31563D	25SA
LAMPS			
Head	1962	58937A	SS700P
Tail and number plate	1962	53429B	529
" " " " Later	1962	53972A	679
Magneto	1962	42417A	NC1
Reflex reflector	1962	57116A	RER25
Switches			
Lighting	1962	31784D	41SA
Stop lamp	1962	31384B	22B
Spring, stop lamp	1962	315543	—

MATCHLESS 500 c.c. o.h.v. 'G80', 'G80S', and 'Major' 1958-62

Alternator			
Rotor	1958-62	423506	RM15
Stator	1958-62	47122A	RM15
Ammeter (part of headlamp)	1958-62	36084F	CZU27
Battery	1958-59	—	PUZ7E-11
	1960-61	—	MLZ9E
	1962	—	PUZ7E-11
Cable harness	1958-59	865225	—
	1960-62	54944148	—
	1962	54949913	—
Coil, ignition	1958-62	45077B/E	MA6
Contact breaker	1958-62	47579D/H	CA1A
Horn	1958-61	*70137A (70048)	HF1441
	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958-59	58135A	MCH57
" " " " " " Later	1960-62	58409A	MCH61
" " " " " " Later	1962	58702A	MCH61
Export, vertical dip	1958-59	58136A	MCH57
Export Europe (not France)	1958-59	58137A	MCH57
" " " " " " Later	1960-62	58514A	MCH61
" " " " " " Later	1962	58832A	MCH61
Export France	1958-59	58138A	MCH57EF
" " " " " " Later	1960-62	58515A	MCH61EF
" " " " " " Later	1962	58833A	MCH61EF
Stop tail, number plate and reflex	1958-62	53432B	564
Rectifier	1958-59	*47111A (47132)	FSW1501A
	1959-62	47132A/B	FSX1849
Switches			
Ignition (part of headlamp)	1960-62	54033027	63SA
ditto	1962	34287A	88SA
Knob	—	54332498	—
Lighting (part of headlamp)	1960-62	54033109	63SA
ditto	1962	34289A	88SA
Knob	—	54330934	—
Lighting and ignition (part of headlamp)	1958-59	31443E	PR58
Knob	—	318346	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

MATCHLESS 500 c.c. o.h.v. 'G80CS' and 'G80CS Marksman' (Competition Models) 1958-62

Alternator			
Rotor	1960-62	423506	RM15
Stator	1960-61	47122A	RM15
" " " " " " Later	1962	47154A	RM15

continued

MATCHLESS 500 c.c. o.h.v. 'G80CS' and 'G80CS Marksman' (Competition Models) 1958-62—continued

Unit	Year	Part No.	Model
Ammeter (part of headlamp)	1958-62	36084F	CZU27
Battery	1958-59	—	PUZ7E-11
	1960-62	—	MLZ9E
	1958	838671	—
Cable harness	1959	54941907	—
" " " " " " Later	1960-61	54945334	—
" " " " " " Later	1962	54949910	—
Control box	1958	37144A	MCR2
" " " " " " Later	—	37144B	MCR2
" " " " " " Later	1959	37232H	RB108
Generator	1958-59	20038B	E3N
Horn	1958-59	*069446 (54068034)	HF1234
" " " " " " Later	1960-61	*70137A (70048)	HF1441
" " " " " " Later	1962	70163A	8H
Horn push	1958-61	76204A	4A
Horn push and dip switch	1962	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958	*50791D (51625)	MU42
" " " " " " Later	1959	58224D	SSU700P
" " " " " " Later	1960-61	58586A	SS700P
" " " " " " Later	1962	58829A	SS700P
" " " " " " Later	1958	53432B	564
Stop tail and number plate	1958	53429A	529
ditto (U.S.A. only)	1959-62	53429A/B	529
ditto	1958-62	*42347D (42371)	NC1
Magneto	—	*42347E (42371)	NC1
" " " " " " (U.S.A. only)	1958-62	42371A	NC1
Rectifier	1960-62	47132A/B	FSX1849
Reflex reflector	1960-62	57116A	RER25
Switches			
Dipper	1958-59	31482A	9
Lighting (part of headlamp)	1960-61	31620A/E	PS9
" " " " " " Later	1958	31340A	U39
" " " " " " Later	1959	*31754A/B (31763)	41SA
" " " " " " Later	1960-62	31784A/D	41SA
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	—	315543	—

MATCHLESS 500 c.c. o.h.v. Twin 'G9' 1958-61 600 c.c. o.h.v. Twin 'G11' 1958 650 c.c. o.h.v. Twin 'G12 Majestic' 1959-62

Alternator			
Rotor	1959-62	423506	RM15
Stator	1959-62	47122A	RM15
" " " " " " Later	1962	47154A	RM15
Battery	650 c.c.—optional	—	PUZ7E-11
	1958-59	—	MLZ9E
	1960-61	—	PUZ7E-11
	1962	—	—
Cable harness	1958	837351	—
ditto (Sports—U.S.A. only)	1958	865136	—
" " " " " " Later	1959	54941756	—
" " " " " " Later	1960-62	54944147	—
" " " " " " Later	1962	54949914	—
ditto (When optional equipment fitted)	1962	54949911	—
Coil, ignition	1959-62	45077B/E	MA6
Control box	1958	37252A	RB108
ditto (Sports—U.S.A. only)	1958	37225E	RB108
Distributor	1959-62	40589D	18D2
Generator	1958	20035A	E3L
Horn	1958-61	*70137A (70048)	HF1441
" (Sports—U.S.A. only)	1958	*70136A (70048)	HF1441
" " " " " " Later	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export, dip left	1958	58177A	MCH57
" " " " " " Later	1958	58151A	MCH57
Home and Export, vertical dip	1959	58354B	MCH57
" " " " " " Later	1960-62	58432A	MCH61
" " " " " " Later	1962	58702A	MCH61
" " " " " " Later	1962	58704A	MCH61
Export, vertical dip	1958	58178A	MCH57
" " " " " " Later	1958	58152A	MCH57
ditto (Sports—U.S.A. only)	1958	*50791D (51625)	MU42
Export, vertical dip	1959	58354B	MCH57
" " " " " " Later	1960-62	58432A	MCH61
Export Europe (not France)	1958	58179A	MCH57
ditto	1958	58153A	MCH57
ditto	1960-62	58516A	MCH61

continued

* When ordering, quote part number shown in brackets



Equipment Specification

MATCHLESS-NORTON

MATCHLESS 500 c.c. o.h.v. Twin 'G9' 1958-61
 600 c.c. o.h.v. Twin 'G11' 1958
 650 c.c. o.h.v. Twin 'G12 Majestic'
 1959-62—continued

Unit	Year	Part No.	Model
LAMPS—continued			
Export Europe .. Later	1962	58832A	MCH61
Export France	1958	58180A	MCH57EF
" Later	1958	58154A	MCH57EF
" Later	1960-62	58517A	MCH61EF
" Later	1962	58833A	MCH61EF
Stop tail and number plate ..	1958-62	53432B	564
Magneto	1958	42230D	K2F
(optional and Sports— U.S.A. only)	1958	*42264A (42380)	K2F
"	1962	*42264D (42380)	K2F
Rectifier	1959	*47111A (47132)	FSW1501
" Later	1959-62	47132A	FSX1849
Switches			
Cutout, magneto (when fitted)	1962	76204A/D	4A
Ignition (part of headlamp) ditto Later	1960-62 1962	54033056 34287A	63SA 88SA
Knob	—	54332498	—
Lighting (part of headlamp) ditto Later	1958 1958	31340A 31754A	U39 41SA
ditto Later	1960-62	54033028	63SA
ditto Later	1962	34289A	88SA
Knob	—	54330934	—
Lighting and ignition (part of headlamp)	1959	*31460A (31443)	PRS8
Knob	—	318346	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

MATCHLESS 500 c.c. o.h.v. 'G9DeL' De Luxe
 Twin 1959 and
 650 c.c. o.h.v. 'G12DeL' De Luxe
 Twin 1959-61

Ammeter	1959-61	36084F	CZU27
Battery	1959	—	PUZ7E-11
"	1960-61	—	MLZ9E
Cable harness	1959	54942037	—
"	1960-61	54944350	—
Control box	1959-61	37252A	RB108
" Later	1961	37252B/D	RB108
Generator	1959-61	20035A	E3L
Horn	1959-61	*70137A (70048)	HF1441
Horn push	1959	76204A	4A
Horn push and dip switch ..	1960-61	31563D	25SA
LAMPS			
Head			
Home and Export, vertical dip	1959	58152A	MCH57
ditto	1960-61	58477A	MCH61
Export Europe (not France) Export France	1960-61 1960-61	58518A 58519A	MCH61 MCH61EF
Stop tail and number plate ..	1959-61	53432B	564
Magneto	1959-61	42230D	K2F
" Later	1961	42230E	K2F
Switches			
Cutout, magneto	1959-61	76204A	4A
Dipper	1959-61	31482A	9
Lighting	1959	*31754A/B (31763)	41SA
Knob	1960-61	54033028	63SA
Stop lamp	1959-61	31384B	22B
Spring, stop lamp	—	315543	—

MATCHLESS 500 c.c. o.h.v. Twin 'G9CS' and
 'G9CSR' 1959 and
 650 c.c. o.h.v. Twin 'G12CS',
 'G12CSR' and 'Monarch' 1959-62

Alternator	1962	423506	RM15
Rotor	—	47154A	RM15
Stator	—	36084F	CZU27
Ammeter (Part of headlamp) (when fitted)	1959-62	36296A	2AR
Battery	1959	—	PUZ7E-11
"	1960-61	—	MLZ9E
"	1962	—	PUZ7E-11
Cable harness	1959	54941907	—
"	1960-61	54945365	—
"	1962	54949911	—
" ditto (12CSR and U.S.A. models)	1962	54949912	—

continued

MATCHLESS 500 c.c. o.h.v. Twin 'G9CS' and
 'G9CSR' 1959 and
 650 c.c. o.h.v. Twin 'G12CS',
 'G12CSR' and 'Monarch' 1959-62
 —continued

Unit	Year	Part No.	Model
Control box	1959-61	37225E	RB108
" Later	1959-61	37225F	RB108
Generator	1959-61	20035A	E3L
Horn	1959	*70136A (70048)	HF1441
"	1960-61	*70137A (70048)	HF1441
"	1962	70163A	8H
Horn push	1959-61	76204A	4A
Horn push and dip switch ..	1962	31563D	25SA
LAMPS			
Head			
Home and Export, vertical dip	1959-61	58224D	SSU700
ditto	1962	58829A	MCH61
ditto (650 c.c.)	1962	58704A	MCH61
ditto (optional)	1962	58258B	F700P
Export, U.S.A. (650 c.c.) ..	1961-62	58556A	SS700P
Export Europe (not France) (650 c.c.)	1962	58830A	MCH61
Export France (650 c.c.) ..	1962	58831A	MCH61EF
Stop tail and number plate ..	1959-62	53429A	529
Magneto	1959	*42264A (42380)	K2F
"	1959-61	*42264B (42380)	K2F
"	1961-62	*42264D (42380)	K2F
Rectifier	1962	47132B	FSX1849
Switches			
Cutout, magneto	1959-62	76204A	4A
Dipper	1959-61	31482A	9
Lighting (part of headlamp) " (650 c.c.—U.S.A.)	1959-61	31754A/B	41SA
ditto	1962	31784D	41SA
Knob	1962	34289A	88SA
Stop lamp	1959-62	31384B	22B
Spring, stop lamp	—	315543	—

NORTON 250 c.c. o.h.v. 'Jubilee' Twin 1960-62

Horn	1960-61	*70153A (70155)	5H
" (Export Switzerland) ..	1960-61	*70136A (70048)	HF1441
LAMPS	1962	70163A	8H
Stop tail and number plate ..	1962	53432B	564

NORTON 348 c.c. o.h.v. '40 International' and
 490 c.c. o.h.v. '30 International' 1958

Ammeter (part of headlamp) ..	1958	36084F	CZU27
Battery	1958	—	PUZ7E-11
Cable harness	1958	838341	—
" Later	1958	839021	—
Control box	1958	37225E	RB108
Generator (part of magdyno) ..	1958	20034A	E3L
Horn	1958	*069239N (54068034)	HF1234
Horn push and dip switch ..	1958	31563A	25SA
LAMPS			
Head			
Home, dip left	1958	*51876B (51954)	MCH58
" Later	1958	51954A	MCH61
Export, vertical dip	1958	58019A	MCH61
Export Europe (not France) Export France	1958 1958	58020A 58021A	MCH61 MCH61EF
Stop tail and number plate ..	1958	53432B	564
Magdyno	1958	46047A	MOIL
Switches			
Lighting (part of headlamp) ditto Later	1958 1958	31340A *31626A (31676)	U39 41SA
Knob	1958	351567	—
" Later	1958	351788	—
Stop lamp	1958	*31437B (54033234)	22B

* When ordering, quote part number shown in brackets



A.J.S. 500 c.c. o.h.v. '18CS', '18CT' and '18CS Southerner' (Competition Models) 1958-62
—continued

Unit	Year	Part No.	Model
Battery	1958-59	—	PUZ7E-11
	1960-62	—	MLZ9E
Cable harness	1958	838671	—
	1959	54941907	—
	1960-61	54945334	—
	1962	54949910	—
Control box	1958	37144A	MCR2
	1958	37144B	MCR2
	1959	37232H	RB108
Generator	1958-59	20038B	E3N
Horn	1958-59	*069446	HF1234
	1960-61	(54068034)	—
		*70137A	HF1441
		(70048)	—
	1962	70163A	8H
Horn push	1958-61	76204A	4A
Horn push and dip switch	1962	31563D	25SA
LAMPS			
Head			
Home and Export	1958	*50791D	MU42
	1959	(51625)	—
	1960-61	58224D	SSU700P
	1962	58586A	SS700P
	1962	58829A	SS700P
Stop tail and number plate	1958	53432B	564
ditto (U.S.A. only)	1958	53429A	529
ditto	1959-62	53429A/B	529
Magneto	1958-62	*42347D	NC1
		(42371)	—
	1962	*42347E	NC1
		(42371)	—
	(U.S.A. only)	42371A	NC1
Rectifier	1960-62	47132A/B	FSX1849
Reflex reflector	1960-62	57116A	RER25
Switches			
Dipper	1958-59	31482A	9
	1960-61	31620A	PS9
	1958	31340A	U39
Lighting (part of headlamp)	1959	*31754A/B	41SA
		(31763)	—
	1960-61	31784A/D	41SA
	1962	34289A	88SA
	1962	54330934	—
Knob	1958-62	31384B	—
Stop lamp	1958-62	315543	22B
Spring, stop lamp	—	—	—

A.J.S. 500 c.c. o.h.v. Twin '20' 1958-61
600 c.c. o.h.v. Twin '30' 1958 and
650 c.c. o.h.v. Twin '31 Swift' 1959-62

Unit	Year	Part No.	Model
Alternator	1959-62	423506	RM15
Rotor	1959-62	47122A	RM15
Stator	1962	47154A	RM15
(650 c.c., optional)	1962	47154A	RM15
Ammeter (part of headlamp)	1958-62	36084F	CZU27
Battery	1958-59	—	PUZ7E-11
	1960-61	—	MLZ9E
	1962	—	PUZ7E-11
Cable harness	1958	837351	—
(Sports, U.S.A. only)	1958	865136	—
	1959	54941756	—
	1960-62	54944147	—
	1962	54949914	—
(when optional equipment fitted)	1962	54949911	—
Coil ignition	1959-62	45077B/E	MA6
Control box	1958	37252A	RB108
(Sports, U.S.A. only)	1958	37225E	RB108
Distributor	1959-62	40589D	18D2
Generator	1958	20035A	E3L
Horn	1958-61	*70137A	HF1441
		(70048)	—
(Sports, U.S.A. only)	1958	*70136A	HF1441
		(70048)	—
	1962	70163A	8H
Horn push and dip switch	1958-62	31563D	25SA
LAMPS			
Head			
Home and Export			
Dip left	1958	58177A	MCH57
	1958	58151A	MCH57
	1959	58354B	MCH57
Vertical dip	1960-62	58432A	MCH61
	1962	58702A	MCH61
Magneto ignition models	1962	58704A	MCH61
Export, vertical dip	1958	58178A	MCH57
ditto	1958	58152A	MCH57
ditto (Sports, U.S.A. only)	1958	*50791D	MU42
		(51628)	—
	1959	58354B	MCH57
ditto	1960-62	58432A	MCH61
Export Europe (not France)	1958	58179A	MCH57

A.J.S. 500 c.c. o.h.v. Twin '20' 1958-61
600 c.c. o.h.v. Twin '30' 1958 and
650 c.c. o.h.v. Twin '31 Swift' 1959-62
—continued

Unit	Year	Part No.	Model
LAMPS, Head—continued			
Export Europe (not France)			
ditto	1958	58153A	MCH57
ditto	1960-62	58516A	MCH61
ditto	1962	58832A	MCH61
Export France	1958	58180A	MCH57EF
	1958	58154A	MCH57EF
	1960-62	58517A	MCH57EF
	1962	58833A	MCH61EF
Stop tail and number plate	1958-62	53432B	564
Magneto	1958	42230D	K2F
(optional and Sports, U.S.A. only)	1958	*42264A	K2F
		(42380)	—
	1962	*42264D	K2F
		(42380)	—
Rectifier	1959	*47111A	FSW1501A
		(47132)	—
	1959-62	47132A/B	FSX1849
Switches			
Cutout, magneto (when fitted)	1962	76204A/D	4A
Ignition (part of headlamp)	1960-62	54033056	63SA
ditto	1962	34287A	88SA
Knob	1960-62	54332498	—
Lighting (part of headlamp)	1958	31340A	U39
ditto	1958	*31754A	41SA
		(31763)	—
ditto	1960-62	54033028	63SA
ditto	1962	34289A	88SA
Knob	—	54330934	—
Lighting and ignition (part of headlamp)	1959	*31460A	PRS8
		(31443)	—
Knob	—	31834B	—
Stop lamp	1958-62	31384B	22B
Spring, stop lamp	1958-62	315543	—

A.J.S. 500 c.c. o.h.v. Twin '20 Del' De Luxe 1959 and
650 c.c. o.h.v. Twin '31 Del' De Luxe 1959-61

Unit	Year	Part No.	Model
Ammeter	1959-61	36084F	CZU27
Battery	1959	—	PUZ7E-11
	1960-61	—	MLZ9E
Cable harness	1959	54942037	—
	1960-61	54944350	—
Control box	1959-61	37252A	RB108
	1961	37252B/D	RB108
Generator	1959-61	20035A	E3L
Horn	1959-61	*70137A	HF1441
		(70048)	—
Horn push	1959	76204A	4A
Horn push and dip switch	1960-61	31563D	25SA
LAMPS			
Head			
Home and Export, vertical			
dip	1959	58152A	MCH57
ditto	1960-61	58477A	MCH61
Export Europe (not France)	1960-61	58518A	MCH61
Export France	1960-61	58519A	MCH61EF
Stop tail and number plate	1959-61	53432B	564
Magneto	1959-61	42230D	K2F
	1961	42230E	K2F
Switches			
Cutout, magneto	1959-61	76204A	4A
Dipper	1959-61	31482A	9
Lighting	1959	*31754A/B	41SA
		(31763)	—
	1960-61	54033028	63SA
Knob	1960-61	54330934	—
Stop lamp	1959-61	31384B	22B
Spring, stop lamp	—	315543	—

A.J.S. 500 c.c. o.h.v. Twin '20CS' and '20CSR' 1959
and 650 c.c. o.h.v. Twin '31CS' and '31CSR
Hurricane' 1959-62 (Competition Models)

Unit	Year	Part No.	Model
Alternator	1962	423506	RM15
Rotor	1962	47154A	RM15
Stator	1959-62	36084F	CZU27
Ammeter (part of headlamp)	1962	36296A	2AR
(when fitted)	1959	—	PUZ7E-11
Battery	1960-61	—	MLZ9E
	1962	—	PUZ7E-11
Cable harness	1959	54941907	—
	1960-61	54945365	—
	1962	54949911	—
(31CSR and U.S.A. models)	1962	54949912	—

* When ordering, quote part number shown in brackets



A.J.S. 500 c.c. o.h.v. Twin '20CS' and '20CSR' 1959 and 650 c.c. o.h.v. Twin '31CS' and '31CSR Hurricane' 1959-62 (Competition Models)
—continued

Unit	Year	Part No.	Model
Control box	1959-61	37225E	RB108
	1961	37225F	RB108
Generator	1959-61	20035A	E3L
Horn	1959	*70136A (70048)	HF1441
	1960-61	*70137A (70048)	HF1441
	1962	70163A	8H
Horn push	1959-61	76204A	4A
Horn push and dip switch	1962	31563D	25SA
LAMPS			
Head			
Home and Export, vertical dip	1959-61	58224D	SSU700
ditto	1962	58829A	MCH61
ditto (650 c.c. 31CSR)	1962	58704A	MCH61
ditto (optional)	1962	58258B	F700P
Export (U.S.A., 650 c.c.)	1961-62	58556A	SS700P
Export Europe (not France) (650 c.c.)	1962	58830A	MCH61
Export France (650 c.c.)	1962	58831A	MCH61EF
Stop tail and number plate	1959-62	53429A/B	529
Magneto	1959	*42264A (42380)	K2F
	Later	1959-61	*42264B (42380)
	Later	1961-62	*42264D (42380)
Rectifier	1962	47132B	FSX1849
Switches			
Cutout, magneto	1959-62	76204A	4A
Dipper	1959-61	31482A	9
Lighting (part of headlamp)	1959-61	*31754A/B (31763)	41SA
			(650 c.c., U.S.A. only)
	1962	31784D	41SA
	1962	34289A	88SA
Knob	1962	54330934	—
Stop lamp	1959-62	31384B	22B
Spring, stop lamp	—	315543	—

ARIEL 250 c.c. 'Leader' 1958-62

Alternator	1958-59	423506	RM13/15
Rotor	1958-59	468678	RM13/15
Stator	1960-61	423506	RM13/15
Rotor	1960-61	47137A	RM13/15
Stator	1962	54213903	RM18
Rotor	1962	47161	RM18
Stator	1962	47161	RM18
Ammeter	1958-62	36084F	CZU27
Battery	1958-62	—	ML9E
Cable harness			
Models with flasher	1958-61	54940984	—
Models less flasher	1958-61	54941002	—
Cable harness	1962	54949615	—
Coil, ignition (2 off)	1958-62	45077B	MA6
Contact breaker	1958-62	*47580A/E (425379)	4CC
Flasher unit (optional)	1958-62	35013A	FL5
Horn	1958-62	*70146B (70142)	HF1849
	Later	1962	70169A
Horn push	1958	*76207A (76200)	HP26
	1959	76200B	HP26
	1960-62	*76234A (76200)	HP26
Inspection lamp sockets	1958-62	*39517B (301187)	—
LAMPS			
Flasher (optional)	1958-62	53733A/D	628
Head			
Home	1958-61	58204B	MCF575P
	1962	58897A	MCF575P
Export Europe (not France)	1958-61	58396A	MCF575P
	1962	58898A	MCF575P
Export France	1958-61	58397A	MCF575P
	1962	58899A	MCF575P
Stop tail and number plate	1958-62	53394B	564
Rectifier	1958-59	*47111A (47132)	FSW1501A
	1960-62	47132B	FSX1849
Switches			
Dipper	1958-62	*31549A (31482)	99
Flasher (optional)	1958-62	31823A	52SA
Ignition	1958-61	54033003	63SA
	1962	34427A	88SA

ARIEL 250 c.c. 'Leader' 1958-62—continued

Unit	Year	Part No.	Model
Switches—continued			
Knob	1958	54330641	—
	1959-61	54330663	—
Cover	1962	54336307	—
Lighting	1958-61	54033004	63SA
	1962	34289A	88SA
Knob	1958	54330642	—
	1959-62	54330662	—
Neutral gear indicator (optional)	1958-62	31820A	68SA
Stop lamp (front brake)	1958	54033235	22B
" " (rear brake)	1959-62	31384B	22B
	1958-62	*31437B (54033234)	22B
Warning lights			
Flasher (optional)	1958	38188A	WL13
	1959-62	38193A	WL13
Neutral gear indicator	1958	38187A	WL13
	1959-62	38194A	WL13

ARIEL 250 c.c. 'Arrow' 1960-62 and 250 c.c. 'Super Sports Arrow' 1961-62

Alternator			
Rotor	1960-61	423506	RM13/15
Stator	1960-61	47137A	RM13/15
Rotor	1962	54213903	RM18
Stator	1962	47161	RM18
Ammeter (part of headlamp)	1960-62	36084F	CZU27
Battery	1960-62	—	ML9E
Cable harness			
	1960	54945366	—
	1961	54947217	—
	1962	54946920	—
Coil, ignition (2 off)	1960-62	45077E	MA6
Contact breaker	1960-62	*47580E (425379)	4CC
Horn	1960	70157A	HF1849
	Later	1960-61	70142D
	1962	70163A	8H
	1962	70169A	8H
Horn push	1960	76200A	HP26
	Later	1960-62	76234A
LAMPS			
Head			
Home	1960-61	58670A	MCH56
	1962	58892B	MCH56
Export Europe (not France)	1960-61	58672A	MCH56
	1962	58893B	MCH56
Export France	1960-61	58673A	MCH56
	1962	58896B	MCH56
Stop tail and number plate	1960-62	53394B	564
Rectifier	1960-62	47132B	FSX1849
Switches			
Dipper	1960-62	*31549A/B (31482)	99
Ignition (part of headlamp)	1960-61	54033003	63SA
" (Export France, part of headlamp)	1960-61	54033027	63SA
" (part of headlamp)	1962	34427	88SA
Knob	1960-61	54330663	—
Cover	1962	54336178	—
Lighting (part of headlamp)	1960-61	54033004	63SA
" (Export France, part of headlamp)	1960-61	54033028	63SA
" (part of headlamp)	1962	34289A	88SA
Knob	1960-61	54330662	—
	1962	54330934	—
Neutral gear indicator (optional)	1962	31820A	68SA
Stop lamp	1960-62	*31437B (54033234)	22B

ARIEL 350 c.c. o.h.v. 'NH' 'Red Hunter' and 500 c.c. o.h.v. 'VH' 'Red Hunter' 1958-59

Ammeter	1958-59	36084F	CZU27
Battery	1958	—	PUZ7E-9
	1959	—	PUZ7E-10
Cable harness	1958-59	838231	—
Control box	1958-59	37225E	RB108
Generator (part of magdyno)	1958-59	20034A	E3L
Horn	1958-59	*70136A (70048)	HF1441
Horn push and dip switch	1958-59	31563D	25SA
LAMPS			
Head			
Home	1958-59	51929A	MCH60
Export, vertical dip	1958-59	51930A	MCH60
Export Europe (not France)	1958-59	51931A	MCH60
Export France	1958	51820B	SS700PEF
" " Later	1958-59	51932A	MCH60PEF

* When ordering, quote part number shown in brackets