

## RECTIFIER TEST PROCEDURE

Procedure	Battery Connections	Bulb Connections	Conclusions
<p>Rectifier Check Connect a 6 volt battery in series with a 6v. 3w. bulb across the rectifier terminals</p> <p>Reverse battery connections.</p>	<p>Positive—Light Green Positive—White Positive—Brown Positive—Brown</p>	<p>Earthed Earthed Green White</p>	<p>Bulb lights Rectifier O.K.</p> <p>Bulb does not light. Rectifier faulty, replace.</p>
	<p>Negative—Light Green Negative—White Negative—Brown Negative—Brown</p>	<p>Earthed Earthed Green White</p>	<p>Bulb does not light. Rectifier O.K.</p> <p>Bulb lights Rectifier faulty, replace.</p>