



# SERVICE



## BULLETIN

Service Release #6-72  
April 7, 1960

1960 G2 AND G2CS

### GEAR BOX LUBRICATION

Capacity, three (3) pints. See lubrication chart. Drain and refill the transmission after the first 500 miles and check the level at every 1000 miles.

Refill to  $\frac{1}{2}$ " below the bottom of the inspection hole.

### FRONT CHAIN LUBRICATION

Capacity, one (1) pint. Engine oil. Drain and refill the front chain case after the first 500 miles and check the level every 1000 miles.

Refill until the bottom run of the chain is completely covered. Check and fill through the large plug in the center of the cover.

### ENGINE AND FRONT CHAIN LUBRICATION

Above 50° F  
SAE 50

32° F to 50° F  
SAE 30

Below 32° F  
SAE 20

### TRANSMISSION LUBRICATION

Above 32° F  
SAE 50

Below 32° F  
SAE 30

THE INDIAN COMPANY

Service Department