



**1938 AJS 350cc
Models 16, 26, 26T & 26SS**

Description Common	No Off	Model	Year Model	Part No	Part No. Common	Notes
Head, cylinder, less valve guides	1	16	38/16	38-16-E2	38-16-E2	
Head, cylinder, less valve guides, two port	1	26	38/26	38-26-E2	38-26-E2	
Head, cylinder, less valve guides, polished	1	26T & 26SS	38/26T	38-16-E2-P	38-16-E2-P	Ports and Combustion chamber are polished.
Gasket, for cylinder head	1	16, 26, 26T & 26SS	38/16	12268	017105	
Bolt, securing head to barrel	4	16, 26, 26T & 26SS	38/16	FE88	FE88	
Stud, securing carburettor	2	16, 26, 26T & 26SS	38/16	STD-271	000271	1 5/32" by 5/16" by 26 and 22
Nut, for carburettor stud	2	16, 26, 26T & 26SS	38/16	STD-4	000004	5/16" by 26 TPI
Gasket, for carburettor stud	1	16, 26, 26T & 26SS	38/16	STD-581	000581	
T piece, for inlet valve oil feed	1	16, 26, 26T & 26SS	38/16	37-8-E287	37-8-E287	
Lock nut, for T piece	1	16, 26, 26T & 26SS	38/16	STD-5	000005	1/4" by 26 TPI
Needle adjusting screw, for T piece	1	16, 26, 26T & 26SS	38/16	38-G3-E558	38-G3-E558	
Lock nut, for adjusting screw	1	16, 26, 26T & 26SS	38/16	STD-212	000212	
Valve, inlet	1	16, 26, 26T & 26SS	38/16	STD-675	000675	
Valve, exhaust	1	16, 26, 26T & 26SS	38/16	STD-677	000677	
Guide, for valve (inlet or exhaust)	2	16, 26, 26T & 26SS	38/16	STD-660	000660	
Spring, for valve, inner	2	16, 26, 26T & 26SS	38/16	CE-211	010644	
Spring, for valve, outer	2	16, 26, 26T & 26SS	38/16	CE-212	010645	
Collar, for valve spring	2	16, 26, 26T & 26SS	38/16	V2-E209	017267	
Cup, for valve spring	2	16, 26, 26T & 26SS	38/16	37-12-E190	37-12-E190	
Distance sleeve, for spring cup	2	16, 26, 26T & 26SS	38/16	37-12-E191	37-12-E191	
Collet, for valve (each in two pieces)	2	16, 26, 26T & 26SS	38/16	STD-686	000686	
Cap, or thimble, for valve	2	16, 26, 26T & 26SS	38/16	STD-685	000685	
Valve, inlet	2	16, 26, 26T & 26SS	38/16	STD-676-A	000676-A	Includes, stem, inner & outer valve springs, valve spring collar, valve cotter and valve stem cap.
Valve, exhaust	2	16, 26, 26T & 26SS	38/16	STD-677-A	000677-A	Includes, stem, inner & outer valve springs, valve spring collar, valve cotter and valve stem cap.
Rocker box, bare	1	16, 26, 26T & 26SS	38/16	37-12-E61	37-12-E61	
Bolt, fixing rocker box, long, front	1	16, 26, 26T & 26SS	38/16	FE 89	FE 89	Head steady attaches to this bolt
Bolt, fixing box, long, rear	1	16, 26, 26T & 26SS	38/16	STD-374	000374	
Bolt, fixing box, short, front	1	16, 26, 26T & 26SS	38/16	STD-365	000365	1 1/16" by 5/16" by 26 tpi
Bolt, fixing box, short, rear	1	16, 26, 26T & 26SS	38/16	STD-365	000365	1 1/16" by 5/16" by 26 tpi
Washer, for box fixing bolt	4	16, 26, 26T & 26SS	38/16	STD-11	000011	5/16" hole engineers' washer
Cover, for rocker box	1	16, 26, 26T & 26SS	38/16	37-12-E62	37-12-E62	
Fillet, rubber, rocker box side cover	1	16, 26, 26T & 26SS	38/16	37-12-E65	37-12-E65	
Stud, fixing rocker box side cover	4	16, 26, 26T & 26SS	38/16	STD-251	000251	1 1/16" by 2 BA
Nut, knurled, for rocker box side cover stud	4	16, 26, 26T & 26SS	38/16	STD-623	000623	
Washer, fibre, for rocker box side cover stud	4	16, 26, 26T & 26SS	38/16	STD-205	000205	2 B.A.
Oil union, in rocker box, for main pipe	1	16, 26, 26T & 26SS	38/16	STD-508	000508	
Oil union, in rocker box, for valve pipe	1	16, 26, 26T & 26SS	38/16	STD-507	000507	
Metering jet, for rocker oil feed	2	16, 26, 26T & 26SS	38/16	STD-578	000578	

Description Common	No Off	Model	Year Model	Part No	Part No. Common	Notes
Bush, for rocker box	4	16, 26, 26T & 26SS	38/16	STD-653	000653	
Plug, felt, for rocker box	2	16, 26, 26T & 26SS	38/16	MX2-E298	MX2-E298	
Pin, fixing, for felt plug	2	16, 26, 26T & 26SS	38/16	37-8-E159	37-8-E159	
Cap, covering inlet valve spring	1	16, 26, 26T & 26SS	38/16	37-12-E162-I	37-12-E162-I	
Cap, covering exhaust valve spring	1	16, 26, 26T & 26SS	38/16	37-12-E162-E	37-12-E162-E	
Screw, for spring cover cap	4	16, 26, 26T & 26SS	38/16	STD-482	000482	1 1/16" x 1/4" by 26 tpi. Cheese head
Axle, rocker	2	16, 26, 26T & 26SS	38/16	FE 57	017192	
Ring, felt, for rocker axle sleeve	2	16, 26, 26T & 26SS	38/16	D8-E1865	012722	
Nut, for rocker axle	4	16, 26, 26T & 26SS	38/16	STD-3	000003	3/8" by 26 tpi
Sleeve, for rocker axle	2	16, 26, 26T & 26SS	38/16	FE 58	017292	
Washer, plain, for rocker axle	4	16, 26, 26T & 26SS	38/16	STD-10	000010	3/8" hole engineers' washer
Arm, rocker, tappet end, inlet and exhaust	2	16, 26, 26T & 26SS	38/16	FE 60	017216	
Arm, rocker, valve end, inlet and exhaust	2	16, 26, 26T & 26SS	38/16	FE 59	017115	
Arm, rocker, tappet end, inlet and exhaust	2	16, 26, 26T & 26SS	38/16	FE 60	017216	
Arm, rocker, valve end, inlet and exhaust	2	16, 26, 26T & 26SS	38/16	FE 59	017115	